

LUCCI ABYSS SERIES DC CEILING FAN

- •INSTALLATION
- OPERATION
- **●MAINTENANCE**
- WARRANTY INFORMATION

CAUTION

READ INSTRUCTIONS CAREFULLY FOR SAFE INSTALLATION AND FAN OPERATION.



THANK YOU FOR PURCHASING

Thank you for purchasing the latest in energy-saving ceiling fans. This fan runs on DC (direct current) power which gives it the benefit of being super energy efficient while still maintaining high volume air-movement and silent operation.

Energy-saving - The DC motor is the latest technology in fan design. Its highly efficient motor saves up to 65% more energy than ceiling fans with traditional AC motors.

Silent operation – This DC fan motor is programmed with a stabilised current which efficiently reduces motor noise.

Low operating temperature – The DC power is managed effectively which brings down the motor operating temperature to less than 50°C. This results in a much cooler motor than a standard AC fan and increases the longevity of the motor.

6-speed remote control - Regular AC ceiling fans usually come with only 3 speeds, and this DC fan comes complete with a 6 speed remote, which gives a greater choice of comfort levels.

SAFETY PRECAUTIONS

- 1. In Europe: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Cleaning and maintenance shall not be undertaken by children without supervision.
- 2. In Australia: The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- 3. Children should be supervised to ensure that they do not play with the appliance.
- 4. An all-pole disconnection switch must be incorporated into the fixed wiring, in accordance with local wiring rules.

IN AUSTRALIA

WARNING:

FOR SAFE USE OF THIS FAN AN ALL-POLE DISCONNECTION

MUST BE INCORPORATED INTO THE FIXED WIRING IN

ACCORDANCE WITH THE WIRING RULES.

As outline in clause 7.12.2 of AS/NZS 60335-1 for meeting the minimum electrical safety of this standard.





Please note warranty will be void if the installation is without a means for an all-pole disconnection incorporated in the fixed wiring in accordance with the wiring rules.

Example: If a fan is connected to a circuit that can be isolated via an all-pole safety switch at the switchboard, then this is considered to be an all-pole disconnection to the ceiling fan electrical circuit, meeting the requirements of clause 7.12.2 of AS/NZS 60335.1.

A single-pole switch on the active of the receiver input of remote control must also be included in the wiring, and located the same room as the ceiling fan.

- 5. Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
 - Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.
- 6. The structure to which the fan is to be mounted must be capable of supporting four time of the weight of the fan.
- 7. The fan should be mounted so that the blades are at least 2.3 m above the floor in Europe or 2.1 m above the floor in Australia.
- 8. This fan is suitable for indoor, alfresco, and coastal areas. This product is IP66 rated and can be exposed to powerful water jets from any direction. This rating should be maintained during installation.
- 9. Must be assembled and installed by a licensed electrician.
- 10. WARNING: If unusual wobbling or oscillating movement is observed, immediately stop using the ceiling fan and contact the manufacturer, its service agent or suitably qualified persons.
- 11. The replacement of parts of the safety suspension system device shall be performed by the manufacturer, its service agent or suitably qualified persons.
- 12. The fixing means for attachment to the ceiling such as hooks or other devices shall be fixed with sufficient strength to withstand 4 times the weight of the ceiling fan; that the mounting of the suspension system shall be performed by the manufacturer, its service agent or suitably qualified persons.



PARTS LIST

- Unpack your ceiling fan carefully. Remove all parts and hardware.
- Lay out all the components on a smooth surface and make sure no components are missing before
 assembling. If parts are missing, return the complete product to the place of purchase for inspection or
 replacement.
- Check whether the ceiling fan has been damaged during transport. Do not operate/install any product
 which appears damaged in any way. Return the complete product to the place of purchase for inspection,
 repair or replacement.
- Examine all parts, and you should have the following:




Fig. 1

Part	Qty	Part	Qty
Ceiling Canopy Top Cover Component	1	Down Rod	1
Sealed Pads	1	Fan Host Ring Cover	1
Drive Component	1	Down Rod Jointer Cover	1
Hanger Bracket	1	Fan Host Component	1
Bracket Mounting Screws	2	Fan Blade Short Screw	6
Ball Joint	1	Fan Blade Long Screw	3
Celling Canopy Screw	2	Fan Blade	3
Celling Canopy Component	1		




INSTALLING THE FAN

TOOLS REQUIRED:

- Phillips / flat head screwdriver
- Pair of pliers
- Adjustable spanner
- Step ladder
- Wirecutter
- Wiring, supply cable as required by local provincial and national wiring codes and regulations

INSTALLING THE MOUNTING BRACKET

- The ceiling fan must be installed in a location so that the blades are spaced 300mm from the tip of the blade to the nearest objects or walls.
- Install the hanging bracket to the ceiling joist or structure that is capable of carrying a load of at least four times of the weight of fan, with two long screws provided. Ensure at least 30mm of the screw is threaded into the support. (Fig. 2)



NOTE: The bracket screws provided are for use with wooden structures only. For structures other than wood, the appropriate type of screw MUST be used. Ensure the screws used are suitable for the mounting surface and the surrounding environment.

ANGLED CEILING INSTALLATION

The hanging system of this fan is ONLY suitable for flat ceiling installation.

DO NOT install the fan on an angled ceiling.



INSTALLATION OF THE MOUNTING BRACKET (Fig.4)

- 1. Insert the supply cable through the cable entry of the ceiling canopy top cover; (Fig.4.1)
- 2. Install the hanger bracket onto the ceiling; (Fig.4.1)

NOTE: Check and ensure the mounting direction of the hanger bracket is correct and ensure the sealed pad is in place; (Fig.4.2)

3. Connect the supply cable to the terminal block. (Fig.4.1)





Fig. 4.1



Sealed pad



INSTALLATION OF BLADE (Fig.5)

- 1. Turn the fan host ring cover anti-clockwise to the open position and lift up; (Fig.5.1)
- 2. Install the fan blades onto the motor assembly by the three fan blade screws provided; (Fig.5.2)
- 3. Install the fan host ring cover back to the motor assembly. Lock it by turning clockwise. (Fig.5.3)




Fig. 5.1






Fig. 5.2




Fig. 5.3



HANGING OF THE FAN (Fig.6)

- 1. Place the hanger onto the mounting bracket. Ensure the key slot of the hanger ball is positioned on the key pin of the mounting bracket to prevent the fan from rotating when in operation; (Fig.6.1)
- 2. Install the drive component onto the hanger by pushing through the mounting bracket; (Fig.6.2)
- 3. Connect the wiring (Fig.6.3 & Refer to the wiring diagram in Fig.7 for more information)
 - Connect the supply cable from the terminal block to the input of the drive component.
 - Connect the output of the drive component to the cable of the fan assembly.
 - Connect the earth wire to the earth terminal.
 - Ensure the earth terminal is tightened to maintain the earth continuity.
- 4. Check and ensure all wiring connections are secured. (Fig.6.4)




Fig. 6



WIRING DIAGRAM (FIG. 7)

<u>WARNING:</u> FOR YOUR SAFETY ALL ELECTRICAL CONNECTIONS MUST BE UNDERTAKEN BY A LICENSED ELECTRICIAN.

NOTE: AN ADDITIONAL ALL POLE DISCONNECTION SWITCH MUST BE INCLUDED IN THE FIXED WIRING.

NOTE: IF THERE ARE TWO OR MORE DC CEILING FANS INSTALLED IN THE ONE LOCATION, AN ISOLATION SWITCH IS REQUIRED FOR EACH CEILING FAN. THIS IS REQUIRED WHEN PROGRAMMING THE REMOTE AND RECEIVER TO PAIR TOGETHER.

Ensure the motor earth wire is connected to the single earthing terminal block "1" in the diagram below. (Fig. 7)


From mains supply to mounting bracket terminal block:

- 1. Connect the live supply wire to the "L" terminal of the terminal block on the mounting bracket.
- 2. Connect the neutral supply wire to "N" terminal of the terminal block on the mounting bracket.
- 3. Connect earth wire to the earth terminal of the terminal block on the mounting bracket.

From mounting bracket to receiver and motor:

- 4. Connect the supply wiring from the mounting bracket to the input of the DC motor driver remote receiver.
- 5. Connect the output wires of the DC motor driver/receiver to the input wires of the fan motor.

NOTE: Do not connect the light terminal on the output of the driver. The light function is not applicable to this model.





FINISHING THE INSTALLATION

INSTALLATION OF THE CANOPY (Fig.8)

- 1. Ensure the earth wiring is secure and correct, by performing an earthing continuity test from the fan's accessible metal body back to the earth terminal at the terminal block on the mounting bracket.
- 2. Push the canopy up to the ceiling canopy top cover fixed by two screws and the clicks;
- 3. Lock the bottom cover of the canopy by turning anti-clockwise.





Fig. 8



USING YOUR CEILING FAN

REMOTE CONTROL (Fig.9)



- (1) Fan Off
- (2) Light On/Off (*No function for model without light)
- (3) Forward/Reverse
- (4) Speed control of the fan (*Fan can be turned on by pressing any speed control buttons)
- (5) Dimming of the light (*No function for model without light)
- (6) Timer (1hour, 2 hours, 4 hours)
- (7) 1.5V AAA battery x 2 pcs (Included)

Fig. 9

PAIRING REMOTE AND RECEIVER - WHEN 1 DC CEILING FAN IS INSTALLED IN ONE LOCATION

NOTE: Ensure that you have installed a single-pole disconnection switch in the fixed wiring for the fan. **NOTE:** Ensure power to the receiver is ON before pairing the remote with the receiver.

- Turn OFF the mains supply to the fan by on/off wall switch.
- Install the batteries into the remote. Please make sure the polarity of the battery is correct.
- Turn ON the power to the receiver.
- Press and hold the "Forward/Reverse" button on the remote for 10 seconds within 30 seconds of switching the power ON to the receiver of the ceiling fan.
- There will be a notification 'beep' sound from the receiver to indicate that the pairing process is successful.
- Turn ON and change the speed of the ceiling fan via the remote to check the operation and successful pairing.



PAIRING REMOTE AND RECEIVER – WHEN 2 OR MORE DC CEILING FANS ARE INSTALLED IN ONE LOCATION

When two or more ceiling fans are located near each other, you may desire to have the remote/receiver for each fan paired so that the operation of one fan does not affect the operation of the other fans.

NOTE: Ensure that you have installed a single-pole disconnection switch in the fixed wiring for each fan.

NOTE: Ensure power to the Receiver is **ON** before pairing the remote with the receiver.

Remote / Receiver pairing for ceiling fan 1:

- Turn OFF the mains supply to the receivers of both ceiling fans 1 and 2.
- Install the batteries into the remote. Please make sure the polarity of the battery is correct.
- Turn ON the power to receiver 1. Keep the power OFF to receiver 2. (Each ceiling fan must have its own isolation switch so that only the ceiling fan that needs to be paired with the transmitter will be ON).
- Press and hold the "Forward/Reverse" button of transmitter 1 for 10 seconds within 30 seconds of switching the power ON to the receiver of ceiling fan 1.
- There will be a notification 'beep' sound from the receiver to indicate that the pairing process is successful.
- Turn ON and change the speed of the ceiling fan 1 by the transmitter to check the operation and successful pairing.

Remote / Receiver paring for Ceiling fan 2:

- Turn OFF the mains supply to the receivers of both ceiling fans 1 and 2.
- Install the batteries into the remote. Please make sure the polarity of the battery is correct.
- Turn ON the power to receiver 2. Keep the power OFF to receiver 1. (Each ceiling fan must have its own isolation switch so that only the ceiling fan that needs to be paired with the transmitter will be ON).
- Press and hold the "Forward/Reverse" button of **transmitter 2** for 10 seconds within 30 seconds of switching the power ON to the receiver of ceiling fan 2.
- There will be a notification 'beep' sound from the receiver to indicate that the pairing process is successful.
- Turn ON and change the speed of ceiling fan 2 by the transmitter to check the operation and successful pairing.



REPAIRING THE FAN RECEIVER & REMOTE PAIRING

Should the remote and receiver lose control after installation or during use, the pairing of the remote and the receiver must be repaired. Below are the operating symptoms and method to repair the pairing of the DC ceiling fan remote and receiver.

Issues:


- Loss of control Fan is only running at high speed after installation
- Loss of control No reverse function after installation
- Loss of control Remote cannot communicate with the receiver

Solution:

- Switch off the main power of ceiling fan.
- Switch on the main power of the ceiling fan. Follow the same process as described in the 'Paring remote and receiver' section to repair your fan.
- Turn on and select the different speed of the ceiling fan to check the operation of the fan.



CHANGING AN EXTENSION ROD



NOTE: When using extension rods, the lower edge of the fan blades must be more than 2.1m above floor level in Australia and more than 2.3m in Europe.

Note: Extension Rod – Supplied Separately

REPLACEMENT OF AN EXTENSION ROD:

- 1. Uninstall the ball joint, canopy, canopy bottom cover & the down rod joint cover from the fan assembly; (Figure 10.1)
- 2. Replace the original down rod with the extended one. Connect the extended cable (provided with the extension rod) to the wiring of the fan assembly (Fig. 10.2)
- 3. Install the down rod joint cover, canopy bottom cover, canopy & ball joint back to the fan assembly. Ensure all the screws are tightened and secure. (Fig. 10.3)




Fig. 10.1

Note: Extension Rod - Supplied Separately






Fig. 10.2




Fig. 10.3





AFTER INSTALLATION

NOTE: Ceiling fans tend to move during operation as they are mounted on a rubber grommet. If the fan was mounted rigidly to the ceiling, it would cause excessive vibration. Movement of a few centimetres is quite acceptable and DOES NOT suggest any problem.

TO REDUCE THE FAN WOBBLE: Please check that all screws which fix the mounting bracket and down rod are secure.

NOISE:

When it is quiet (especially at night) you may hear occasional small noises. Slight power fluctuations and frequency signals superimposed in the electricity for off-peak hot water control, may cause a change in fan motor noise; this is normal. Please allow a 24-hour "settling-in" period, most noises associated with a new fan disappear during this time.

The manufacturer's warranty covers actual faults that may develop and NOT minor complaints such as hearing the motor run – All electric motors are audible to some extent.

CARE & CLEANING

NOTE: Always turn OFF the power at the mains switch before performing any maintenance or attempting to clean your fan.

- Every 6 months periodic cleaning of your ceiling fan is the only maintenance required. Use a soft brush or lint-free cloth to avoid scratching the paint finish. Please turn off electricity power when you do so.
- Do not soak or immerse your ceiling fan in the water or other liquids. It could damage the motor or the blades and create the possibility of an electrical shock.
- Ensure that the fan does not come in contact with any organic solvents or cleaners.
- To clean the fan blade, wipe with only a damp clean cloth with NO organic solvents or cleaners.
- The motor has a permanently lubricated ball bearing so there is no need to oil.

SAFETY PRECAUTIONS FOR BATTERY

- WARNING Keep new and used batteries away from children.
- **CAUTION** Do not ingest battery—Chemical burn hazard.
- Always use 2 x AAA battery type with this ceiling fan remote controller.
- Ensure the batteries are inserted with the correct polarity.
- The ceiling fan must be disconnected from the supply mains to prevent false operation during battery insertion or replacement.
- Remove batteries from the product when not in use for long periods.
- Batteries must be removed from the remote transmitter before it is discarded.
- Dispose of exhausted batteries immediately and safely (so they cannot be retrieved by children). Batteries can still be dangerous. Contact your local council to dispose of the battery safely.
- Regularly check the product and make sure the battery box lid is correctly secured. If the battery compartment does not close securely, stop using the product and keep it away from children.

Airfusion Abyss Installation Instructions



- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. If you suspect your child has swallowed or inserted a button battery, immediately call the 24-hour Poisons Information Centre on **13 11 26** for fast, expert advice.
- Battery Leaks: Battery contains chemicals and should be treated as any chemical would. Take precautions
 when handling leaked battery chemicals. Battery chemicals should not be placed near the eyes or
 ingested. Contact Poisons Information Centre on 13 11 26 for fast, expert advice.

TECHNICAL INFORMATION			
Fan	IP66 DC Fan		
Fan Models	Aqua 66	Aqua 70"	
Rated Voltage	220 - 240V~ 50Hz		
Rated Wattage (Motor)	26W	55W	
Battery for remote	2 x AAA (Included)		
Weight	5.5kg	7.0kg	
Canopy Dimensions	H:77mm Dia:158mm		



LUCCI CEILING FAN WARRANTY DETAIL

LUCCI WARRANTY HOTLINE- 1800 602 243

THIS WARRANTY IS VALID IN AUSTRALIA ONLY

In the event of service is required, please call the Lucci Fan Warranty Hotline on 1800 602 243 between 9 am & 5 pm (EST) Monday to Friday. Please make sure you have all the ceiling fan details filled out at the end of the manual before making the call.

Every Lucci ceiling fan is thoroughly inspected and tested before being released for sale. In addition to any warranty rights or conditions under statutory regulations, Lucci warrants all of its ceiling fans against defective workmanship and faulty materials for twenty-four (24) months from the date of purchase. Lucci undertakes, at its option, to repair or replace, free of charge, each product or part thereof on condition that;

- 1. The fan or relevant part has not been subjected to misuse, neglect, or been involved in an accident.
- 2. The repairs are not required as a result of normal wear and tear.
- 3. The product was installed by a licensed electrical contractor.
- 4. A copy of the original receipt of purchase is presented.
- 5. 12-month warranty applies when used in any non-domestic applications.
- 6. This warranty does not cover stains, scratch and scuff marks, or dents if the product is purchased through a factory outlet or to refurbished items.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Lucci Design cannot be held responsible for any repair other than those carried out by it or one of its Authorised Service Agents. Please keep this warranty information in a safe place. This information must be produced in the event of service being required.

Distributed by:

Beacon Lighting 140 Fulton Drive Derrimut, Victoria, 3026 Australia Ph +613 9368 1000

Fax +613 9360 9332

Email: warranty@beaconlighting.com.au





CEILING FAN WARRANTY INFORMATION

LUCCI WARRANTY HOTLINE- 1800 602 243

Complete and retain this form for your personal records and warranty purposes.

NAME	
ADDRESS	
	POSTCODE
MODEL NUMBER	
PO NUMBER or DATECODE	(PO# + DATECODE Sticker here)
INSTALLING LICENSED ELECTRICIAN	
LICENCE No	
ATTACH PROOF OF PURCHASE HERE	

THIS COMPLETED DETAIL PAGE SHOULD BE PRODUCED AND FAXED TO THE WHOLESALER OR THEIR AUTHORISED AGENTS BEFORE OBTAINING WARRANTY SERVICE