

JASPER LED TABLE LAMP

SKU# 250540, 250541

Rated Voltage 220 – 240V~

Thank you for purchasing this quality Lucci product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of the product. Please keep the instructions for future reference.

Warranty

- This product is covered by a 3-year warranty. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the product.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation requirements


- Select a suitable location for the luminaire;
 - Ensure it is on a flat and stable surface.
 - This product is suitable for indoor use only.
 - Do not place flammable material near or over the luminaire.
 - Ensure the luminaire is not placed next to any air vents and is not in any moist or damp areas.
 - If the luminaire is placed in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure no components are missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable lamp is fully assembled and ready to use for the first time.

Installation & Operation directions

1. Remove all packaging material from the luminaire.
2. Insert the plug into the mains socket outlet and ensure it is fully plugged in.
3. Use the ON/OFF switch to turn the luminaire ON/OFF.
4. Adjust the lamp head to your preferred lighting angle.

NOTE: The maximum angle of adjustment for the arm is 180° in the horizontal direction and 90° to the vertical position.

When adjusting the arms, do not adjust more than the angles as above, as this may damage the internal wiring.



Safety tips

- Always ensure the power is OFF and the luminaire has cooled down before performing any maintenance, cleaning or adjustment to the luminaire.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- The external flexible cable or cord of this luminaire cannot be replaced; if the cable or cord is damaged, the luminaire shall be destroyed.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life, the whole luminaire shall be replaced.
- Young children should be supervised to ensure that they do not play with the portable lamp.
- Handle the luminaire and shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.
- To clean, wipe with a damp clean cloth. Never soak the luminaire with water.

Specifications

SKU #	250540	250541
Model #	DE19011BLK	DE19011WH
Colour	Black	White
Rated Voltage	220 – 240V ~	
Rated Power	4.5W	
LED Specs	4.5W, 300 lumen, CRI >80, CCT 3000K	
Weight	0.8 kg	
Dimensions	H: Max.400mm W: 170mm L: Max.220mm	