

CLIQUE II LED MULTI-FUNCTION LIGHT WITH MOTION SENSOR

SKU# 250916

Rated Voltage 4.5V / 3.7V DC

Thank you for purchasing this quality Lucci product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this luminaire. Please keep the instructions for future reference.

Warranty

- This luminaire is covered by a 12 month warranty from the date of purchase. Please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

Installation Requirements

- Battery: 3 x 1.5VDC AA battery (Not included) OR 1 x 3.7VDC 18650 rechargeable Li-ion battery (Not included)
- Select a suitable location for this luminaire:
 - This luminaire is not waterproof.
 - This luminaire is suitable for indoor use only.
 - Keep away from liquids, dusty, humid, direct sun light, cooking areas or hot areas.
- Lay out all the components on a smooth surface and make sure there are no components missing. If parts are missing, return the complete luminaire to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any luminaire which appears damaged in any way. Return the complete luminaire to the place of purchase for inspection, repair or replacement.

Operation Directions

Battery installation/Replacement

- 1. Open the lid of the battery compartment on the back of the luminaire.
- 2. Install 3 x AA batteries (Not included) OR 1 x 18650 Li-ion battery (Not included) into the battery compartment. Ensure the batteries are inserted with the correct polarity.
- 3. Install the lid back over the battery compartment and ensure it is secure.

Operation

1. Use the 'ON/OFF/AUTO' switch to turn the luminaire on/off or to the motion sensing mode.

ON position – The luminaire will be permanently on;

OFF position - The luminaire will be permanently off;

AUTO position – The luminaire will be turned on automatically when any motion is detected. It will be turned off after 20 seconds if no motion is detected. (NOTE: The luminaire will only be activated when the ambient light < 10lux)

2. Stick the magnet on the metal surface of the desired location.

NOTE: There is a metal plate provided with '3M' adhesive tape in case no metal surface is found on the desired location.


Ensure the surface is smooth, dry and clean before applying the '3M' adhesive tape.

Charging

1. Charge the luminaire via the USB charging port if rechargeable 18650 Li-ion battery is installed.

NOTE: The luminaire MUST NOT be charged when the 3 x AA batteries is installed.





Safety Tips and Warnings

- This luminaire is NOT a toy. Keep out of reach of small children.
- Young children should be supervised to ensure that they do not play with this luminaire.
- Remove batteries from the luminaire when not in use for long periods of time.
- To clean, wipe with a soft damp cloth or duster. Do NOT soak or immerse the luminaire in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.
- Dispose of exhausted batteries immediately and safely (so they cannot be retrieved by children). Contact your local council to safely dispose of the battery.

Specifications	
SKU #	250916
Colour	Black
Rated Voltage	4.5V / 3.7V DC, 3.2W
LED Specs	Cool white, 6000K, 200 lumen
	PIR Sensor
Motion Sensor	Detection range & angle: Max.8M, 120 degree
Specs	Recommend installation height: 1.5 – 2M
	Activate when ambient light < 10lux
Battery	3 x 1.5V AA batteries (Not included)
	OR 1 x 3.7V 18650 rechargeable Li-ion battery (Not included)
Weight	0.2kg
Dimensions	H:105mm L: 105mm W: 88mm