


NELSON LED TABLE LAMP

SKU# 259949, 259950, 259951, 259952, 259953

Rated Voltage 12-27V  0.3A

Thank you for purchasing this quality Lucci product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of the product. Please keep the instructions for future reference.

Warranty


- This fitting is covered by a 3 year warranty from the date of purchase. Please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the product.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

Installation Requirements

- Select a suitable location for this light fitting;
 - Ensure it is on a flat and stable surface.
 - This product is suitable for indoor use only.
 - Do not place flammable material near or over the fitting.
 - Ensure the fitting is not installed in direct line of an air vent/system.
 - If installing a fitting in an area prone to moisture, ensure that the area is well ventilated and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Only use the supplied plug in LED driver with this fitting.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable lamp is fully assembled and ready to use for the first time.

Installation Directions

1. Remove all packaging material from the product.
2. Select a suitable location for the light fitting. See the installation requirements above.
3. Adjust the arm (D) of the fitting to the desired height and angle.
NOTE: When adjusting the arm (D) do not bend more than 45° as this may damage the internal wires.
See diagram on the next page.
4. Insert the connector (B) into the base (C) of the fitting.
5. Insert the LED driver (A) into the mains socket outlet and ensure it is fully plugged in.
6. Turn power on at the mains power socket outlet.
7. Use the switch (E) on the base to turn the lamp on/off.




NOTE: When adjusting the angle of the arm (D), do not bend more than 45° as this may damage the internal wires.

Safety Tips

- Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning or adjustment to the fitting.
- To avoid injury or damage to the fitting, ensure that power leads and screws are secure before connecting the power.
- Young children should be supervised to ensure that they do not play with the portable lamp.
- The LEDs are not replaceable and there are no serviceable parts, do not attempt to dismantle or open the product.
- Handle the fitting and/or shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the fitting does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	259949	259950	259951	259952	259953
Colour	Matte Black	Matte White	Blue	Mint	Red
Rated Voltage	12-27V  0.3A				
Rated Wattage	6.5W (including driver)				
LED Specs	280 Lumens, 3000K Warm White, Non-dimmable				
Weight	1.2kg				
Dimensions	H:525mm L:450mm W:460mm				