

Assembly and Safety Instruction

Before Use, please read the following instructions carefully in order to avoid any functional disorders or damages.

The mentioned voltage of **220V-240V ~ 50Hz** should comply with the voltage of your electricity system.

If this is not the case do **not** connect the lamp.

The bulb to be used for the lamp should be **E27 maximum 60W GLS or CFL compatible bulb**.

If you use a bulb with a higher wattage the lamp holder could be damaged.

Assembly of the lamp

Caution : Be sure that the electricity is turned off at the power source before proceeding with the installation.


1. Reach out the lamp from the package carefully.
2. Put the shade on the lamp holder and put metal cap on the shade. Screw the ring on the lamp holder.
3. Screw the bulb (**E27 Max. 60W GLS or CFL compatible bulb, not included**) into the lamp holder.
4. Connect the plug into mains supply. Switch on/off the lamp with touch base.

Maintenance and Care

1. Always carry the lamp by holding the stand.
2. Before replacing a defective bulb unplug the lamp and let it cool down for at least 10 minutes.
Only change the bulb if it has completely cooled down. Use a clean fluff-free cloth to change the bulb.
3. If necessary, the lamp can be cleaned with a clean dry or slightly damp cloth.

Caution: please unplug it at least 10 minutes before cleaning.

4. The lamp should be placed on a dry and clean surface.
5. The lamp is designed for indoor use only.
6. If the external cable or cord of this luminary is damaged, shall be replaced by the manufacturer or his service agent or a similar qualified person in order to avoid hazard.



ITEM NO.: TS400S-C