

Installation Instructions
SKU# 260410 (LD-T59469T-SI)
Rated Voltage 230-240V~ 50Hz

PLEASE READ AND SAVE ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT


WARNING - to reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation.

INSTALLATION REQUIREMENTS:

- Do not exceed the maximum wattage rating
- Suitability for use “indoors”

INSTALLATION DIRECTION:

- Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
 - Take care not to pull wire during unpacking as a bad connection may occur.
 - Ensure all power connection is off for your own safety.
 - Level all the components on a smooth surface and make sure there is no component missing before assembly.
1. Attach harp (B) to saddle of socket assembly (A).
 2. Place the shade (C) onto the harp (B), then tighten Finial (D) clockwise to secure the Shade.



TIPS:

1. To avoid injury or damage to the fitting, ensure that power leads and screws are secure before connecting the power.
2. Handle the fitting and cover/shade with care to avoid breakage.
3. When changing or cleaning bulbs, turn OFF power and allow to cool. Do not touch bulbs with bare hands, use gloves or a tissue.
4. Find a suitable location away from liquids and hazards.
5. Ensure that the fitting does not come in contact with corrosive chemicals, etc.
6. To clean, wipe with a damp clean cloth. Never soak the fitting with water.

SPECIFICATIONS:

SKU #	MODEL #	RATED VOLTAGE	RATED WATTAGE	LAMP HOLDER
260410	LD-T59469T-SI	230-240V~ 50Hz	60W MAX.	B22

PLEASE READ AND SAVE ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT