

SARITA 3 LIGHT TABLE LAMP

SKU# 261538, 261539

Rated Voltage 220-240V~ 50Hz.

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this luminaire. Please keep instructions for future reference.

Warranty

- This portable luminaire is covered by a 12-month warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the portable luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements


- Select a suitable location for the portable luminaire:
 - Ensure it is on a flat and stable surface.
 - This portable luminaire is suitable for indoor use only.
 - Do not place flammable material near or over the portable luminaire.
 - If the portable luminaire is placed in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable luminaire is fully assembled with the lamp installed and is ready to use for the first time.

Installation Directions

1. Remove all packaging material from the portable luminaire.
2. Place the portable luminaire on a smooth non-scratch surface to help with assembly.
3. Install lamps (D – not included) into the lamp holders (C). Do not exceed the maximum wattage rating.
4. Install the decorative beads (A – 75 sets) onto the luminaire ring (B). Start the installation on the lower inner ring, followed by the higher outer ring.
5. Select a suitable location for the portable luminaire. See the installation requirements above.
6. Insert the plug into the mains power socket outlet and ensure it is fully plugged in.
7. Turn power on at the mains power socket outlet.
8. Use the cord line switch (E) to turn the portable luminaire ON or OFF.

RELAMPING

1. Ensure the power is turned OFF to the portable luminaire and allowed to cool down.
2. Remove the lamp from the lamp holder by twisting it anticlockwise and replace with a new lamp.



Safety Tips

- Always ensure the power is OFF and the portable luminaire has cooled down before performing any maintenance, cleaning or making any adjustment to the portable luminaire.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Young children should be supervised to ensure that they do not play with the portable luminaire.
- Handle the luminaire and shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

Specifications

SKU #	261538	261539
Colour	Aged Brass Finish	Chrome
Rated Voltage	220-240V~ 50Hz	
Rated Wattage	84W Max.(3x Max. 28W)	
Lamp Holder	SES / E14	
Weight	3.9 kg	
Dimensions	H:500mm Dia:250mm	