

## ARBOR 1 LIGHT FLOOR LAMP

SKU# 286130

Rated Voltage 220-240V~ 50Hz

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep the instructions for future reference.

### Warranty

- This portable luminaire is covered by 12 months warranty valid for in-store replacement or refund only.
- The warranty period starts from the date of purchase. Please retain the proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the portable luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

### Installation requirements


- Select a suitable location for the portable luminaire:
  - Ensure it is on a flat and stable surface.
  - This portable luminaire is suitable for indoor use only.
  - Do not place flammable material near or over the portable luminaire.
  - Ensure the portable luminaire is not installed in direct line of an air vent/system.
  - If the portable luminaire is placed in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- Do not exceed the maximum wattage rating.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable lamp is fully assembled with the globe installed and is ready to use for the first time.

### Installation directions

1. Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material. Place the portable luminaire on a smooth non-scratch surface to help with assembly.
2. Select a suitable location for the portable luminaire . See the installation requirements above.
3. Install the lamp holder section (A) onto the top rod (H) followed by the middle rod (C) followed by the bottom rod (D) and then onto the base (K). Pull the cord out from the base (K) as you assemble to remove any slack in the cord.

**NOTE: Take care not to cross thread or twist and damage the cord during assembly. Check the supply cord after every three turns when installing the bottom rod (D) to the thread. Carefully relieve the twist of the supply cord by anti-clockwise with the same turns before further steps.**

4. Install the shade (J) onto the lamp holder section (A) and secure with the lamp holder ring (I) and lamp holder cover (H).
5. Install globe (G-not included) into the lamp holder. Do not exceed the maximum wattage rating.
6. Insert the plug (F) into the mains power socket outlet and ensure it is fully plugged in.
7. Turn power on at the mains power socket outlet. Use the cord line switch (F) to turn the portable luminaire on and off.



**Safety tips**

- Always ensure the power is OFF and the portable luminaire has cooled down before performing any maintenance, cleaning or making any adjustment to the portable luminaire.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- Young children should be supervised to ensure that they do not play with the portable luminaire.
- Handle the luminaire and shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the product in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

**Specifications**

SKU #	286130
Rated Voltage	220-240V~ 50Hz
Rated Wattage	45W Max.
Lamp Holder	ES / E27
Weight	11.6 kg
Dimensions	H:1800mm Dia:500mm