CAVIUS PHOTOELECTRIC SMOKE ALARM

THE WORLD'S SMALLEST



PLEASE READ THIS USER GUIDE CAREFULLY

CAVIUS

CAVIUS Photoelectric Smoke Alarm Part Code: 2008-003/10014/10020/10028 Model: 2008-001 Recess Kit Part Code: 11010

PLEASE READ THE USER GUIDE CAREFULLY BEFORE INSTALLATION AND RETAIN FOR FUTURE USE.

For large text option and maintenance guide visit

cavius.co.nz/support


cavius.com.au/support




The best locations in your home to install the smoke alarm:

- Place a smoke alarm between possible fire sources and bedrooms as a minimum.
- Smoke alarms on each floor, in hallways and stairways.
- Smoke alarms in each room such as bed rooms and living rooms.

Additional alarms will increase the safety. The NZ and Australian Fire Services recommend smoke alarms in every bedroom, hallway and living area for early fire detection.




Placement: Designed for placement on ceiling (preferred) or wall. The smoke alarm should be a minimum 50cm from the wall, with a minimum of one smoke alarm per floor and a maximum distance between smoke alarms of 10 metres.



For catheral or peak ceiling:

For cathedral or peak ceiling; a minimum of 50cm from the peak.



The smoke alarm may NOT be installed:

- In dusty rooms.
- Within 100cm of a heat pump, air conditioning unit or air vent also not in direct line of any these systems.
- Within 40cm from the edge of a ceiling fan blade.
- · Within 30cm of a light fitting.
- In rooms where the temperature goes outside +5° to 45°C or above 90% relative humidity non-condensing.
- In kitchens, garages, or laundry we recommend a thermal heat alarm.

Place the smoke alarm where it is reachable to test the battery and complete maintenance.

6

Maintenance:


The smoke alarm should be vacuum cleaned minimum once per quarter and can be wiped

with a slightly damp cloth (do not open the alarm). Ensure to vacuum all the way around the stainless steel mesh.

Test the smoke alarm once per month by pushing the test button. The smoke alarm should produce a loud alarm tone.



 Using your hole saw (44mm-48mm), cut a hole into the surface. AUTION: Ensure there is no wiring or any electrical equipment behind the surface you are drilling your hole into.



Smoke alarm signal: The smoke alarms have a visual and acoustic signal. In the passive state, the LED will flash every 48 seconds to indicate normal function. In alarming state the LED will flash and the alarm will emit a sweeping sound pattern designed to alert occupants.



q


Installation of smoke alarm:

Info: The label on the product must not be removed due to important information.

Option 1 - Standard base

 Use the mounting base ring to mark the screw holes on the ceiling.





Option 2 – Recess Kit


1. Place the Cover Ring on the area where you wish to install the smoke alarm, trace around the inside of the ring.



 After mounting, allow 5 seconds for the alarm to power up and then test the smoke alarm by pushing the test button (which is the entire bottom of the alarm).
The alarm should produce a loud sound.



Hush function: In case of unintentional or false alarms, press and hold the hush button for 2 seconds (which is the entire bottom of the alarm). This will mute the alarm for 10 minutes, after which time the alarm will automatically resume its normal function.



14

FUNCTIONAL INFORMATION

Type of alarm: CAVIUS smoke alarm is a photoelectric smoke alarm.

Alarm signal: Fire alarm activation is indicated by a series of repeated tones. The minimum sound level is 85 dB at 3 metres.

Battery: Powered by a non-replaceable CR123A 3V, 1600mAh with 10-year life (included).



Low battery indicator: A short acoustic "beep" will sound and the LED will flash every 48 seconds when the battery is near the end of its life. In this stage it will continue for a minimum of 30 days.

Please replace smoke alarm: You must change the smoke alarm after 10 years of use, or if the smoke alarm has suffered any damage. The smoke alarm is not active unless it is clicked into the mounting base.

Always test the smoke alarm after clicking into the mounting base, allow 5 seconds before testing.

Fault finding: If the smoke alarm activates without a visible smoke or fire presence, then possible causes could be:

 Dust particles which have entered the smoke chamber, these can be removed by vacuuming around the mesh chamber.

If the smoke alarm does not work when the test button is pushed, please check our Trouble Shooting Guides at;

cavius.co.nz and cavius.com.au

Disposal: For product, please dispose properly at end of life. The alarm can be recycled at an electronic waste recycling centre.

Other information:

- Do not paint the smoke alarm.
- Note the local country regulations regarding installation of mains powered smoke alarms in new buildings.

The CAVIUS smoke alarm is a photoelectric alarm designed to be installed into residential homes, camper-vans and caravans. It is not recommended for boats.



Certified to Australian Standard AS3786:2014

Developed & Manufactured by:

Carrier Fire & Security Danmark A/S, Ellekær 9A, 2. Th, DK-2730, Denmark cavius.com

Distributor information:

for New Zealand - CAVIUS Nano Ltd. 58a Poplar Lane, Papamoa 3187, NZ.

www.cavius.co.nz

for Australia - CAVIUS Australia PTY LTD GPO Box 303, Brisbane, QLD 4001, Australia. www.cavius.com.au

Warranty:

CAVIUS provides a 10-year warranty against defect in faulty material and workmanship from the date of purchase, on all devices.

The varranty applies to reasonable and normal conditions of use only. It does not include damage as a result of misuse, incorrect installation, accidental damage, neglect, unauthorised deconstruction or dismantling and any airborne or other contamination however this may have occurred.

If this product has an acknowledged defect it must be returned to the national CAVIUS distributor at the purchasers cost with the proof of purchase.

If the product has become defective within the 10-year warranty, CAVIUS APS, Denmark will repair or replace the unit without charge and send back to the purchaser, via the national distributor at the distributors cost.

The guarantee excludes labour costs, freight costs, service costs and any incidental and consequential damages. Do not attempt to repair or service this product as this will invalidate the warranty.

20

Product overview:

Type of mounting		Ceiling a Mounting	nd Wall
Main power supply		Internal power source (battery included)	
Interconnectable device		Yes	No 🗹
Suitable for installation in mobile home		Yes 🗹	No
Connection to external auxiliary devices		Yes	No 🗹
Alarm silence facility (10min)		Yes 🗹	No

127479 rev2

CAVIUS

REGISTER YOUR CAVIUS PRODUCT WITH US & GO IN THE DRAW TO WIN

CAVIUS.CO.NZ/WARRANTY