### SIGMA ADJUSTABLE SURFACE MOUNT DOWNLIGHT

SKU# 160125, 160126

Rated Voltage 220-240V~ 50Hz

To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep instructions for future reference.

#### Warranty

- This luminaire is covered by a 5-year warranty. The warranty is from the date of purchase, not the date of installation.
- If the luminaire is not assembled and installed by a licensed electrician, the warranty will be void.
- Please retain the proof of purchase and evidence of installation by a licensed electrician for any warranty enquiries.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

### Installation Requirements

- This luminaire must be assembled and installed by a licensed electrician.
- All wiring and installation of the luminaire must adhere to the latest local and national wiring rules.
   E.g. AS/NZS 3000 Electrical Installations.
- This luminaire is a Class I product and must be earthed during wiring and installation.
- This luminaire must be used with GU 10 LED lamps only. Do not exceed the maximum wattage rating.
- Select a suitable location for installation:
  - This luminaire can be installed on the ceiling or the wall.
  - This luminaire is suitable for indoor use only.
  - The mounting point must support 2 times the weight of the luminaire.
  - Ensure the luminaire is not installed in direct line of an air vent/system.
  - If installing a luminaire in an area prone to moisture, ensure that the area is well ventilated, and an appropriately
    rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such
    is not covered under warranty.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure no components are missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Ensure power to the circuit you are working on has been switched OFF before commencing any electrical work.

### Installation Directions

NOTE: This luminaire can be installed on the ceiling or the wall, both installation methods are the same.

- 1. Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material.
- Remove the mounting bracket by loosening the screws on the sides of the luminaire with the allen key provided (Fig 1).
- 3. Remove the shade from the luminaire by twisting it anti-clockwise direction. (Fig 1).
- 4. Use the mounting bracket as a template to mark the screw positions on the ceiling/wall (Fig 2).
- 5. Install the mounting bracket onto the ceiling/wall by using appropriately sized mounting screws and anchors. Ensure the screws and anchors used are suitable for the mounting surface and the surrounding environment (Fig 3).

 Connect the mains supply wire to the terminal block. Ensure the wires are secure and no bare wires are exposed (Fig 4).

Mains Supply Wire	Luminaire Wire / Terminal Block
Earth – Yellow/Green	Yellow/Green or 圭
Neutral – Blue or Black	Blue or N
Active – Brown or Red	Brown or A

#### NOTE: This luminaire is a Class I product and must be earthed during wiring and installation.

- 7. Install the luminaire onto the mounting bracket and secure by tightening the screws on the sides of the luminaire (Fig 5-A).
- 8. Install a globe (not included)into the lamp holder (Fig 5-C).


#### NOTE: This luminaire must be used with GU 10 LED lamps only. Do not exceed the maximum wattage rating.

- 9. Push the globe inside the luminaire (Fig 5-B).
- 10. Install the shade back into the luminaire by twisting it clockwise (Fig 5-D).
- 11. Adjust the luminaire to your desire angle (Fig 6).

#### NOTE: The maximum angle of rotation for the luminaire is 325°

12. After the installation, switch on the luminaire to test and enjoy your new lighting product.


### Installation Diagram for Ceiling Mount



NOTE: The maximum angle of rotation for the luminaire is 325°

# Lucci

## Installation Diagram for Wall Mount



### NOTE: The maximum angle of rotation for the luminaire is 325°

### Safety Tips

- Always ensure the power is OFF and the luminaire has cooled down before performing any maintenance, cleaning, changing the globe or making any adjustment to the luminaire.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the luminaire in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.

## Lucci

Specifications		
SKU #	160125	160126
Colour	White	Black
Rated Voltage	220-240V~ 50Hz	
Rated Wattage	8W Max. (LED lamps only)	
Lamp Holder	GU10	
Weight	0.4kg	
Dimensions	H:180mm W:120mm E:60mm	