VECTOR DIMMABLE COLOUR SHIFTING LED FLUSH MOUNT

SKU# 181046, 181047, 181048, 181049

Rated Voltage 220-240V~ 50Hz

Thank you for purchasing this quality Lucci product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of this product. Please keep instructions for future reference.

Warranty

- This luminaire is covered by a 3-year warranty. The warranty is from date of purchase, not the date of installation.
- If the luminaire is not assembled and installed by a licensed electrician, the warranty will be void.
- Please retain the proof of purchase and evidence of installation by a licensed electrician for any warranty enquiries.
- The use of non-compatible dimmers may damage your LED luminaire and will void your warranty.
- Warranty will be void if there is any damage due to improper usage or modification to the luminaire.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void the warranty.

Installation Requirements

- This luminaire must be assembled and installed by a licensed electrician.
- All wiring and installation of the luminaire must adhere to the latest local and national wiring rules. E.g. AS/NZS 3000 Electrical Installations Do not exceed the maximum wattage rating.
- The luminaire is a Class I product and must be earthed during wiring and installation.
- Select a suitable location for installation:
 - This luminaire is suitable for indoor use only.
 - The mounting point must support 2 times the weight of the luminaire.
 - Ensure the luminaire is not installed in direct line of an air vent/system.
 - If installing a luminaire in an area prone to moisture, ensure that the area is well ventilated, and an appropriately rated exhaust fan is used if required. Damage or corrosion caused by moisture is not a product fault, and as such is not covered under warranty.
- This luminaire is dimmable and was tested with the dimmers listed in the specification section at the date of publication. The use of a LED dimmer such as the Lucci LEDlux SKU# 290998 or SKU# 290997 is highly recommended.

NOTE: For the best dimming range, use the Lucci LEDlux SKU# 290998 dimmer and adjust the variable resistor at the minimum and maximum dimming positions on the dimmer during the installation.

NOTE: Dimming may cause buzzing sounds or a slight flicker. There may be slight delays with the LED luminaire start-up or uneven light performance when more than one LED luminaire is linked together, switched ON or dimmed. This is not a product fault and as such is not covered under warranty.

NOTE: Some dimmers have a minimum load of 20W. Ensure the dimmer position is on the maximum setting before turning on the LED light and adjust the dimmer down to your desired light level.

NOTE: Testing cannot account for installation variables such as variation in mains supply voltage, cable capacitance, electrical noise, transients, surges and ripple control signals (commonly found in NSW & QLD).

NOTE: The information provided is correct to the best of Beacon Lighting's knowledge at the date of publication.

- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure no components are missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the luminaire has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Ensure power to the circuit you are working on has been switched OFF before commencing any electrical work.



Installation Directions

NOTE: Due to the size of the luminaire, two people may be required to lift it up during the installation process.

- 1. Remove all packaging material from the product and be careful not to throw away accessories that may be hidden within the packaging material. If assembly is required, place the luminaire on a smooth non-scratch surface.
- 2. Use the supplied template to mark the screw holes for the mounting brackets. (Fig. 1)
- 3. Remove the mounting brackets from the luminaire by loosening the screws on the side.
- 4. Install the mounting brackets onto the ceiling by using appropriately sized mounting screws and anchors. Ensure the screws and anchors used are suitable for the mounting surface and the surrounding environment. (Fig. 2)
- 5. Open the cover on the terminal box and connect the mains supply wire to the terminal block. (Fig. 3)

Mains Supply WireLuminaire Wire / Terminal BlockEarth – Yellow/GreenYellow/Green or 🚽Neutral – Blue or BlackBlue or NLive – Brown or RedBrown or L

NOTE: The luminaire is a Class I product and must be earthed during wiring and installation.


- 6. Ensure the wires are secure and no bare wires are exposed. Firmly close the cover on the terminal box.
- 7. Install the luminaire onto the mounting brackets and secure by tightening the screws on the sides. (Fig. 4)
- 8. Use the switch on the side of the luminaire to select the colour temperature (3000K/4000K/5000K) you desire. (Fig. 5)

NOTE: Before using the switch to select the colour temperature, the luminaire MUST be switched OFF, or it may damage the LED driver.

9. After the installation is complete, switch on the luminaire to test all functions before the licensed electrician leaves.

Safety Tips

- Always ensure the power is OFF and the luminaire has cooled down before performing any maintenance, cleaning or making any adjustment to the luminaire.
- To avoid injury or damage to the luminaire, ensure that power leads and screws are secure before connecting the power.
- Select a suitable location away from liquids and hazards.
- To clean, wipe with a soft damp cloth. Do NOT soak or immerse the luminaire in water or other liquids.
- Ensure that the luminaire does not come in contact with corrosive chemicals/solvents or abrasive cleaners etc.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life, the whole luminaire shall be replaced. There are no serviceable parts, do not attempt to dismantle or open the product.



NOTE: Before using the switch to select the colour temperature, the luminaire MUST be switched OFF, or it may damage the LED driver.

Installation Instructions



Troubleshooting					
PROBLEM	POSSIBLE CAUSE	SUGGESTED SOLUTION			
	Loose wiring or no power to the luminaire.	Check your circuit breaker/safety switch box and			
Does not work.		turn on the power to your circuit.			
(New installation)		Contact the installing licensed electrician to check if			
		the luminaire has been installed correctly.			
Does not work. (Existing installation)		Check your circuit breaker/safety switch box and			
	No power to the luminaire.	turn on the power to your circuit.			
		Contact your nearest Beacon Lighting store.			
Flickers when dimming. (New installation)	Non-recommended dimmer used.	Check the dimmer used. Ensure the dimmer used is			
		on the list of recommended dimmers in this manual.			
	Some dimmers have a variable loading				
	adjustment function. e.g. Lucci LEDlux	The variable resistor needs to be adjusted to suit the			
	SKU# 290998 dimmer.	luminaire load to reduce the flickering.			
	This may not have been adjusted during				
	the installation of the dimmer.				
Flickers when		Ensure the dimmer position is on the maximum			
dimming.	Dimmer position on low.	setting before turning on the luminaire and adjust the			
(Existing installation)		dimmer down to your desired light level.			
Buzzing cound	Non-recommended dimmer used.	Check the dimmer used. Ensure the dimmer used is			
Buzzing sound.		on the list of recommended dimmers in this manual.			
Uneven light on start-up	Dimmer position on low when switched on.	Ensure the dimmer position is on the maximum			
		setting before turning on the luminaire and adjust the			
		dimmer down to your desired light level.			

Specifications						
SKU #	181046	181047	181048	181049		
Colour	Matte White	Matte Black	Matte White	Matte Black		
Rated Voltage	220-240V~ 50Hz					
Rated Wattage	28W Max.		36W Max.			
LED Specs	Colour switching LEDs*, Dimmable, CRI>90					
Lumens	3000K – 1850 lumens		3000K – 2300 lumens			
	4000K – 2000 lumens		4000K – 2500 lumens			
	5000K – 1900 lumens		5000K – 2400 lumens			
Highly Recommended	Lucci LEDlux SKU# 290998, SKU# 290997, SKU# 299043					
Dimmers						
Compatible Dimmers	Buster + Punch DIM-002.					
	DIGINET LED Smart MEDM.					
	Clipsal 31E2RUDM, 32E450TM, 32E450UDM, 31E2PUDM and 32ELEDM.					
	HPM Cat. 400T.					
Weight	1.1	1.1kg 1.6kg		δkg		
Dimensions	H:42mm L:120	0mm W:32mm	H:42mm L:180	0mm W:32mm		

* Before using the switch to select the colour temperature, the luminaire MUST be switched OFF, or it may damage the LED driver.